



Challenge: The red warning lights on the bus flash for no apparent reason on Blue Bird buses equipped **with air brakes** and **with manual door and brake interlock**.

Possible Cause: These particular buses have a wiring harness that is used on many Blue Bird models, and the harness contains wire #1532L (Yellow w/Black tracer).

This wire was intended to be used in bus models that have air door cylinders. The wire would run from the compartment and connect to an air door cylinder.

As these affected buses have no air door cylinders, the wire should have a butt connector on the end. Unfortunately, some of the #1532L wires were left with an eyelet on them by mistake, and this eyelet can ground against the body causing the red warning lights to activate.

Solution: Locate the #1532L wire (see photo below) and check to see if it has been grounding out. If it has, cut the eyelet off and crimp a butt connector on the wire and cover in electrical tape.



YANCEY
Bus Sales & Service

YANCEY BUS SALES & SERVICE

"Your Blue Bird® Dealer for Georgia & Alabama"

1-866-MY-B-BIRD (1-866-692-2473)

www.YanceyBus.com